





Product Beauty Catalog



PRODUCT CATALOG

Central Control Units	1
Enclosures, Enclosure Lids & Backboxes	3
Control Modules	4
Keypads	9
Scenario	19
Accessories & Replacement Parts	20

CENTRAL CONTROL UNITS



The Mastermind Behind Great Lighting Control:

LiteTouch Central Control Units



All LiteTouch systems are controlled by a Central Control Unit (CCU) which is the brain of the system. It receives switch press information from the keypad, processes the commands and transmits the instructions to the Control Modules. It retains switch and load assignment information indefinitely, even during a power outage or spike. Best of all, LiteTouch CCUs are easily reprogrammed at any time to suit the user's needs.

FEATURES		TOUCH C STANDARD	5000LC
Programmable Fade Rates	•	•	•
Programmable Ramp Rates	•	•	•
Random Vacation Mode	•	•	•
Diagnostic LEDs and Software	•	•	•
Minimum Dimmer Turn On	•	•	•
RF and IR Remotes*	•	•	•
Unlimited Scene Presets	•	•	•
Master Dimmer Turn On	•	•	•
Variable Speed Motor Control	•	•	•
Interface Capabilities:	•	•	•
Environment Controls (HVAC)	•	•	•
Security Systems	•	•	•
Motion Sensors, Photo Cells	•	•	•
Audio/Video	•	•	•
Daily / Weekly / Date Time Flags	•	•	•
Multiple Location Control	•	•	•
Group Mastering	•	•	•
Timed Off Function	•	•	•
RS-232 Port / Computer Interface	•	•	•
Pathway Lighting	•	•	•
Invert LEDs	•	•	•
Restore Feature	•	•	•
Manual Override	•	•	•
On Again to Previous Dim Level	•	•	•
Preset Locks	•	•	•
Astronomical Time Clock	•	•	•
Telephone Interface With Modem		*	•
Self-Contained Programmability (No lapt	op required)	•	
Sequential Programming			•
Conditional Programming			•
Control Station Lockout			•
Switch Lockout			•
Master Conditions on All Switch Types			•
Load / Switch Description Programming			•
Combination Locks			•
Custom Switch Types			•
Upgradable Firmware			•
Ethernet Communication Enabled *Optional feature			*
SPECIFICATIONS	COMPACT	standard	5000LC

256

100

40

256

256

Control Stations

Control Modules

CENTRAL CONTROL UNITS





5000LC CCU

The 5000LC Central Control Unit is the flagship processor for LiteTouch. This CCU offers all the capabilities of standard lighting control plus conditional/sequential logic, startup events, user defined programming and an

expandable design to accommodate the most advanced features in lighting control. The CCU has four Control Module ports and four keypad ports inside the CCU's backbox.

The 5000LC CCU's rack mount design enables it to stay at the technological forefront by offering upgradeable cards. The seven card slots provide for future expansion of modems and ethernet cards. A built-in redundant processor in the controller cabinet provides fail safe operations.

Every 5000LC Card Set contains the following:

CPU Card:

Provides the processing of a LiteTouch system. This card is available with either one or two serial ports.

Connection Card:

Provides communication to modules and stations in a LiteTouch system. Acts as a backup for switch to load programming in the 5000LC.

Monitor Card:

The 5000LC Monitor card provides power switching of the 5000LC CCU and low voltage suppression for LiteTouch station and module communication.

Available 5000LC Upgrades:

CPU Card with ethernet capabilities:

(One serial port plus one ethernet port) See above for product description.

Modem Card:

Provides user control of the LiteTouch system via the telephone and allows diagnostic access from a remote location for programming control and modifications.

The 5000LC Card set is required for the CCU to function.

Dimensions

14" H x 16" W x 5" D

Catalog Numbers

5000LC Enclosure w/power supply: 08-5000-00 5000LC 3-Card Blank Slot Cover: 08-5000-28 5000LC 4-Card Blank Slot Cover: 08-5000-30

PHONE: 801.486.8500

Individual Cards:

Monitor Card: 08-5000-18 Serial Only CPU Card: 08-5000-20 Ethernet/Serial Enabled CPU Card: 08-5000-40

Connection Card: 08-5000-22 Modem Card: 08-5000-26

CCU Card Packs (also requires 08-5000-00):

CCU Card Pack with Ethernet/Serial Enabled CPU Card

08-5000-08

08-5000-10: with Modem Card

CCU Card Pack with Serial Only Enabled CPU Card

08-5000-04

08-5000-06: with Modem Card



Compact CCU

The Compact Central Control Unit offers system control of smaller LiteTouch systems. The CCU has two Control Module

ports and two keypad ports. The CCU is programmed via the RS-232 Serial port.

Dimensions

8 1/2" H x 12 1/4" W x 1" D

Catalog Number

08-2001-10



Standard CCU

The Standard Central Control Unit offers system control of larger LiteTouch sys-

tems. This CCU has four Control Module ports and four keypad ports. The Standard CCU has optional modem capabilities for telephone interfacing. A unique LCD display allows for programming and diagnostic review without a computer.

Dimensions

8 3/4" H x 12 1/2" W x 2 1/2" D

Catalog Numbers

Standard CCU: 08-2000-01

Standard CCU with modem: 08-2000-06

ENCLOSURES, ENCLOSURE LIDS & BACKBOXES



Solutions Program: Powerful solutions for Your Custom Programming and Integration needs.

Maximize the functionality of the 5000LC CCU with the help of the new LiteTouch Solutions Program. Solutions can help you:

- · Specify your job
- · Write your full program
- · Create custom switch types
- · Enhance pre-existing programs
- · Program your jobs right the first time

Whether you're brand new as a LiteTouch Dealer, or don't have time to program, separate yourself from the competition by utilizing the power of LiteTouch Solutions and the 5000LC Lighting Control System.

Call LiteTouch Tech Support (1-800-527-5527) for more details.

CCU Factory Programming

LiteTouch CCU Factory Programming provides LiteTouch dealers with advanced programming design for complex applications. This programming may also be used for newer dealers requiring assistance on their first LiteTouch projects.

Call LiteTouch Tech Support (1-800-527-5527) for more details.

Factory Checkout and Technical Onsite Service

To ensure the installation of your LiteTouch system meets the same high standards set by the factory, LiteTouch offers the Factory Checkout. This is an onsite inspection by a LiteTouch Certified Systems Inspector.

Call LiteTouch Tech Support (1-800-527-5527) for more details.



5000LC CCU Enclosure with Power Supply

The 5000LC CCU Backbox houses the 5000LC back-plane board and power supply.

It is made of heavy-gauge steel covered with a wheat-colored, non-corrosive protective coating. The 5000LC Card Set is ordered separately and slides into the individual card positions to connect with the back-plane. It is installed at the same time as the initial rough-in.

Dimensions

14" H x 16" W x 5" D

Catalog Numbers

08-5000-00 (also requires one of the 5000LC Card Sets: 08-5000-06 or 08-5000-04. See Previous Page.)



CCU Backbox

The Surface Mount CCU Backbox is a simple rough-in box for the Standard or Compact


CCU. The CCU mounts to the side of the backbox allowing the hinged CCU to swing open for easy wiring access.

Dimensions

8" H x 11" W x 4" D

Catalog Number

08-8025-01



CCU Backbox With Wiring Harness

The CCU Backbox with Wiring Harness provides a termination point for the keypad and module

runs. This is a perfect option for projects with more than 60 keypads. The wiring harness allows for quick connection of both module and keypad wires. For use with Compact and Standard CCUs only.

Dimensions

Surface Mount: 14" H x 11 3/4" W x 4" D Recessed Mount: 14" H x 11 3/4" W x 4" D

Catalog Numbers

Surface Mount: CCU Backbox With Wiring Harness:

08-8025-03

Recess Mount: CCU Backbox With Wiring Harness:

08-8025-04

WEB: www.LiteTouch.com TECH SUPPORT 1.800.527.5527





Four Module Enclosure

The LiteTouch Four Module Enclosure houses four individual LiteTouch Modules. It is made of heavy gauge steel and has a corrosion protectant seal. The latched lids can be surface or recess mounted.

Now Available

Additional Transorb Boards can be added to the Enclosure for each individual module to increase equipment protection.

Now Available

The Enclosure Voltage Separator can be added to any Enclosure to enable 120 and 277 volt modules to mount within the same enclosure. *Note:* Ensure this meets your local electrical code prior to specification.

Dimensions

Four Module Enclosure: 37" H x 20" W x 4" D Lids: Recessed Mount: 38.5" H x 20.6" W Surface Mount: 36.8" H x 19.8" W

Catalog Numbers

Four Module Enclosure: 08-8024-01

Lids: Surface Mount: 08-8024-02 (Includes Latch Kit)

Recessed Mount: 08-8024-03 (Includes Latch &

Recess Installation Kit)

Enclosure Voltage Separator: 08-8024-20



Two Module Enclosure

The LiteTouch Two Module Enclosure houses two individual LiteTouch Modules. It is made of heavy gauge steel and has a corrosion protectant seal. The lids can be surface or recess mounted.

Dimensions

Enclosure: 20" H x 20" W x 4" D Recessed Mount Lid: 22" H x 22" W Surface Mount Lid: 20" H x 20" W

Catalog Numbers

Two Module Enclosure: 08-8024-08

Lids: Surface Mount: 2580-022

Recessed Mount: 2580-024

PHONE: 801.486.8500



LiteTouch Control Modules

Utilizing safe, low-voltage control signals, LiteTouch provides the flexibility to control lights from many different locations.

Master Control

Master switches permit monitoring and control (even in groups) of every light in the home; an easy way to save energy costs by

selectively turning off groups of lights. Control Modules are the work horses of the system that make this functionality possible.

Convenience & Functionality

LiteTouch Modules create a level of convenience impossible to achieve with conventional wiring. They not only switch lights on and off, but offer a full range of dimming as well.

The Heart of a Hard-working System

At their very heart, Control Modules are high-tech printed circuit boards mounted in aluminum cans, which are secured in LiteTouch's own enclosures. Although simplistic in their design, Control Modules can't be underestimated, as their rugged design and functionality make any lighting design you can imagine a reality. Control Modules bring a whole new dimension of unparalleled beauty and functionality to any home--big or small.

Communication Made Possible

The LiteTouch System can also integrate with virtually every system within the project, making your home a truly automated home.



How Do I Know What Modules I Need?

Below is a list of load types and modules best suited to handle those load types.

LOAD TYPE	RECOMMENDED MODULE
Incandescent 1 to 15 Amp	Eight Channel Dimmer Module High Power Relay Module
Incandescent 16 to 20 Amp	Quad Dimmer Module Dual 20 Amp Dimmer Module
Low Voltage Incandescent (Magnetic Transformer)	Eight Channel Dimmer Module High Power Relay Module
Low Voltage Incandescent Electronic Transformer Dimmer Module	Eight Channel Dimmer Module Electronic (Inverse Phase) Dimmer Module High Power Relay Module
Forward Phase Control Fluorescent Dimming Ballast	Eight Channel Dimmer Module
Motor Loads (i.e. fans, disposals, pumps)	High Power Relay Module Fan Speed Control Module
Wall Outlets	High Power Relay Module
Fluorescent (non-dimming) Fluorescent (dimming)	High Power Relay Module Fluorescent Dimmer Module
Fluorescent Magnetic Dimming Ballast	Electronic Ballast (0-10 VDC) Dimmer Module
Neon/Cold Cathode (non-dimming) Neon/Cold Cathode (dimming)	High Power Relay Module Eight Channel Dimmer Module
High/Low Intensity Discharge (non-dimming)	High Power Relay Module
Motion Control (motorized window treatments, skylights, pool covers, etc)	High Power Relay Module
Low Voltage (HVAC, Audio/Video, alarms, some window treatment controls)	Low Voltage Relay Module
Non-system Information Interface (Security, home automation, radio frequency, etc.)	Momentary Contact Data Input
Non-system Information Interface (Photocells, motion sensors, garage door openers)	Maintained Contact Data Input



8 Channel Dimmer Module

The 8-Channel Dimmer Module provides dimming of incandescent,

neon, cold cathode, forward phase control fluorescent ballasts, and magnetic low voltage transformer loads. The module is rated at 20 Amps or 2400 watts (de-rated to 1920 watts) at 120 VAC, 4400 watts (de-rated to 3520 watts) at 240 VAC, and 5540 watts (de-rated to 4432 watts) at 277 VAC.

Note: The Enclosure Voltage Separator can now be added to the Enclosure to enable various voltage modules within the same enclosure. Ensure this meets your local electrical code prior to specification.

Dimensions

10 3/4" W x 7 5/8" H x 3" D

Catalog Numbers

120 v: 08-2108-01 240 v: 08-2108-02 277 v: 08-2108-03



Dual 20 Amp Dimmer Module

The Dual 20 Amp Dimmer Module provides dimming of large incandescent, neon, cold cathode, forward

phase control fluorescent ballasts, and magnetic low voltage transformer loads. The module has two 20 Amp inputs and a de-rated output of 1920 watts per output. Feeds must be on the same phase.

Dimensions

10 3/4" W x 7 5/8" H x 3" D

Catalog Number

120 v: 08-2125-01

PHONE: 801.486.8500 WEB: www.LiteTouch.com TECH SUPPORT 1.800.527.5527





Quad Dimmer Module

The Quad Dimmer Module provides dimming of large incandescent, neon,

cold cathode forward phase control, fluorescent ballasts, and magnetic low voltage transformer loads. The module has two 20 Amp inputs and a de-rated output of 1920 watts (120 VAC) or 3840 watts (240 VAC) for each pair of outputs. Feeds must be on the same phase.

Dimensions

10 3/4" W x 7 5/8" H x 3" D

Catalog Numbers

120 v: 08-2134-01 240 v: 08-2134-02



Fluorescent Dimmer Module

The Fluorescent Dimmer Module provides dimming of fluorescent loads with magnetic dimming ballasts. The module has one 20 Amp input and a de-rated output of 1920 watts (120 VAC), 3840 watts (240 VAC) or 4432 watts (277 VAC) distributed over four fused outputs.

Note: The Enclosure Voltage Separator can now be added to the Enclosure to enable various voltage modules within the same enclosure. Ensure this meets your local electrical code prior to specification.

Dimensions

10 3/4" W x 7 5/8" H x 3" D

Catalog Numbers

120 v: 08-2138-01 240 v: 08-2138-02 277 v: 08-2138-03



Inverse Phase Dimmer Module

The Inverse Phase Dimmer Module provides dimming of solid state low-voltage electronic transformer loads. The module has one 20 Amp input and a de-rated output of 1920 watts (120 VAC) or 3840 watts (240 VAC) distributed over six outputs with a maximum 480 watts (120 VAC) or 960 watts (240 VAC) per output.

Dimensions

10 3/4" W x 7 5/8" H x 3" D

Catalog Numbers

120 v: 08-2140-01 240 v: 08-2140-02



Electronic Ballast Dimmer Module

The Electronic Ballast Dimmer Module (0-10 VDC) provides dimming of electronic fluorescent ballasts that require an analog input with switched 120 VAC.

Note: The Enclosure Voltage Separator can now be added to the Enclosure to enable various voltage modules within the same enclosure. Ensure this meets your local electrical code prior to specification.

Dimensions

10 3/4" W x 7 5/8" H x 3" D

Catalog Numbers

120 v: 08-2150-01 240 v: 08-2150-02 277 v: 08-2150-03





The Fan Speed Control Module provides three-speed control of ceiling fans. The module has four outputs rated at two amps. Each output provides control of one fan.

Note: Not suitable for electronic ceiling fans.

Dimensions

10 3/4" W x 7 5/8" H x 3" D

Catalog Number

08-2118-01



35 Amp Auxiliary Mercury Relay Module

Switches loads that are too heavy for conventional LiteTouch Relay Modules. This

module must be mounted upright to work properly.

Dimensions

2" W x 5" H x 2 1/4" D

Catalog Number

08-2230-01

Low Voltage Relay Module

The Low Voltage Relay Module provides low voltage dry contact closure to devices such as skylights, draperies, blinds, pool/spa pumps, etc. The module has eight outputs and requires DC power input from a LiteTouch power supply. It occupies one half of a module can.

Dimensions

10 3/4" W x 7 5/8" H x 3" D

Catalog Number

08-2235-01

Nower Supply Modules

The LiteTouch Power Supply Modules provide DC power to Low Voltage Relay Modules, Data Input Modules, Keypads, Data Input Keypads, and Standard and Compact CCUs. Each Power Supply is rated at two Amps and occupies one half of a module can.

Note: The Enclosure Voltage Separator can now be added to the Enclosure to enable various voltage modules within the same enclosure. Ensure this meets your local electrical code prior to specification.

Dimensions

10 3/4" W x 7 5/8" H x 3" D

Catalog Numbers

Single Power Supply Module 120 v : 08-8610-01

240 v: 08-8610-03

Dual Power Supply Module 120 v: 08-8620-01

240 v: 08-8620-03



High Power Relay Module

The High Power Relay Module provides switching of large loads. The module has

eight inputs and eight outputs. Each output is rated for 20 Amps de-rated. Consecutive outputs cannot exceed 30 Amps.

Note: The Enclosure Voltage Separator can now be added to the Enclosure to enable various voltage modules within the same enclosure. Ensure this meets your local electrical code prior to specification.

Dimensions

10 3/4" W x 7 5/8" H x 3" D

Catalog Numbers

120 v: 08-2210-01 240 v: 08-2210-02

277 v: 08-2210-03

PHONE: 801.486.8500 WEB: www.LiteTouch.com TECH SUPPORT 1.800.527.5527





Maintained Contact Data Input Module

The Maintained Contact Data Input Module provides sensing of dry contact closure from a third party device. The module allows third party devices to trigger events in the LiteTouch System. The module has eight inputs and is powered from the control station line. It occupies one half of a module can.

Dimensions

10 3/4" W x 7 5/8" H x 3" D

Catalog Number

08-2290-01



Momentary Contact Data Input Module

The Momentary Contact Data Input Module provides sensing of momentary dry contact closure from a third party device. The module allows third party devices to trigger events in the LiteTouch system including Dimming a load from a momentary switch. The module has eight inputs and is powered from the control station line. It occupies one half of a module can.

Dimensions

10 3/4" W x 7 5/8" H x 3" D

PHONE: 801.486.8500

Catalog Number

08-2290-02



Combination Modules

Some modules only take up half of the space of one Module can and are able to be com-

bined with other Modules. The following are the possible Module combinations:

Catalog Numbers

- Power Supply/Low Voltage Relay: MIXED 001
- Power Supply/Momentary Contact Data Input Module: MIXED 002
- Power Supply/Maintained Contact Data Input Module: MIXED 003
- Low Voltage Relay/Momentary Contact Data Input Module: MIXED 004
- Low Voltage Relay/Maintained Contact Data Input Module: MIXED 005
- Momentary/Maintained Contact Data Input Module: MIXED 006
- Dual Low Voltage Relay Module: DUAL 001
- Dual Momentary Contact Data Input Module: DUAL 002
- Dual Maintained Contact Data Input Module : DUAL 003

Dimensions

10 3/4" W x 7 5/8" H x 3" D



More Beauty For Your Lighting Control System:

LiteTouch Keypads



LiteTouch Keypads connect in parallel and have their own selectable address for communication with the CCU. This concept allows simple wiring while preserving total flexibility. It is possible to independently assign any control keypad switch to control any load. Any given load can be controlled from several different control keypads, or any switch can be assigned to simultaneously control many loads (a master mode).

Custom made Keypads are available in up to eight gangs.

Six Steps to Ordering a LiteTouch Keypad

- 1. Choose the **Keypad style** and insert it in the Keypad's catalog number where specified.
- 2. Choose the **faceplate finish** from premium or standard finishes and add to the catalog number where specified.
- 3. Choose the **number of buttons** to go on the Keypad and insert it in the catalog number where specified.

PHONE: 801.486.8500

- 4. Choose the **button color**, engraving and fill and add to the catalog number where specified.
- 5. Once the catalog number has been created, submit it with your order and **specify quantity**, **description** and **per unit price** (individual dealer pricing is provided by your Authorized Representative).
- Authorized Dealers and Reps Fax your completed purchase order to LiteTouch, Inc., 801.486.8569. You may also email your order to your designated Inside Sales Associate.

WEB: www.LiteTouch.com TECH SUPPORT 1.800.527.5527





Polished Gold Faceplate with Nine Bl Backlit Buttons

Metropolitan Series Keypad

Metropolitan Keypad Features:


- Small, square buttons.
- One to nine buttons in a single gang.
- LED status indicators embedded onto the button
- Engraved buttons with up to two lines of text, 8 characters per line.
- Optional nite-light mode makes it easy for guests to turn on the lights even in the dark.

Optional Upgrades:

- Backlit buttons makes fast work of finding just the right scene every time (up to two lines of text, 5 characters per line).
- Add IR to your keypad and see how convenient lighting control can be from your couch.


Catalog Numbers

# of Buttons	<u>Standard</u>	With Backlit Buttons
1	MET-X01-XXX	MET-B01-XXX
2	MET-X02-XXX	MET-B02-XXX
3	MET-X03-XXX	MET-B03-XXX
4	MET-X04-XXX	MET-B04-XXX
5	MET-X05-XXX	MET-B05-XXX
6	MET-X06-XXX	MET-B06-XXX
7	MET-X07-XXX	MET-B07-XXX
8	MET-X08-XXX	MET-B08-XXX
9	MET-X09-XXX	MET-B09-XXX



Example: MET-B01-MO2X (1-button Metropolitan Style Keypad with Backlit buttons, Dark Oil Rubbed Bronze faceplate, black buttons and no IR).

Metropolitan Series keypad Dimensions





S-Series Keypad

S-Series Keypad Features:

- Small, square buttons
- One to nine buttons in a single gang (see the Standard Single-Gang Keypad Configurations chart on page 16 for details).
- Rectangular LED inset just above button.
- Engraved buttons with up to two lines of text, 8 characters per line.

Dimensions

See the chart on the bottom of page 11 for double and single gang Keypad dimensions.


Catalog Numbers

Single Gang Keypads

of Buttons	Standard
1	08-2501-XXXX
2	08-2502-XXXX
3	08-2503-XXXX
4	08-2504-XXXX
5	08-2505-XXXX
6	08-2506-XXXX
7	08-2507-XXXX
8	08-2508-XXXX
9	08-2509-XXXX

Double Gang Keypads

# of Buttor	<u>ns</u> <u>Standard</u>
12	08-2512-XXXX (6+6)
15	08-2515-XXXX (9+6)
18	08-2518-XXXX (9+9)



Note: Standard Keypads do not have a bezel therefore the second position will hold an X

Example: 08-2508-WX9X (8-button "S" Series Keypad, with white faceplate, buttons, and no infrared)

S-Series IR Only Keypads

Single-gang Keypad with an IR receiver in the ninth position (see page 16 for Keypad configurations) behind an S-Series style IR window. Call to order.





H-Series Keypad

H-Series Keypad Features:

- Sleek, horizontal buttons with an LED inset on the right side of the button
- One to nine buttons in a single gang (see the Standard Single-Gang Keypad Configurations chart on page 16 for details)
- Engraved buttons with one line of text, 10 characters per line.

Dimensions

See chart on the bottom of page 11 for double and single gang Keypad dimensions.


Catalog Numbers

Single Gang Keypads

sirigie Gariy	Reypaus
# of Buttons	<u>Standard</u>
1	08-2901-XXXX
2	08-2902-XXXX
3	08-2903-XXXX
4	08-2904-XXXX
5	08-2905-XXXX
6	08-2906-XXXX
7	08-2907-XXXX
8	08-2908-XXXX
9	08-2909-XXXX

Double Gang Keypads

# of Buttons	<u>Standard</u>
12	08-2912-XXXX (6+6)
16	08-2916-XXXX (8+8)
18	08-2918-XXXX (9+9)



Note: Standard Keypads do not have a bezel therefore the second position will hold an X. Infared = I No Infared = X

Example: 08-2908-WX9X (8--button "H" Series Keypad with white faceplate and buttons, and no infrared.)

H-Series IR Only Keypad

PHONE: 801.486.8500

Single-gang Keypad with an IR receiver in the ninth position (see page 16 for keypad configurations) behind an H-Series style shaped IR window. Call to order.



E-Series Keypad Features:
- Large, easy to read:

- Large, easy to read square buttons with a LED inset just above.
- One to four buttons in a single gang (see the Standard Single-Gang Keypad Configurations chart on page 16 for details)
- Engraved buttons with two lines of text, 8 characters per line.


Dimensions

See chart on the bottom of the page for double and single gang Keypad dimensions.

E-Series Keypad

Catalog Numbers


Single Gang	Keypads	Double Gang Keypads	
# of Button	<u>S</u>	# of Buttor	<u>ns</u>
1	08-2401-XXX	5	08-2405-XXX
2	08-2402-XXX	6	08-2406-XXX
3	08-2403-XXX	7	08-2407-XXX
4	08-2404-XXX	8	08-2408-XXX



Example: 08-2404-WX9 (4-button "E" Series Keypad with white faceplate and buttons.)

Note: E-Series Keypads do not have a bezel option therefore the second position must hold an X.

S-Series, H-Series and E-Series Keypad Dimensions



WEB: www.LiteTouch.com





SatiLite Wall-Box Dimmer (1 & 2 Button)

The SatiLite Wall-box Dimmer functions like a traditional wall-box dimmer but with added features. As the name indicates, it becomes an extension of the LiteTouch System and can be controlled by other button presses on key-


pads. For example, a "Master On/Off" or "Vacation" button could be programmed to control a load connected to a SatiLite. It can control inductive, neon, cold cathode, low-voltage magnetic transformer and incandescent loads. The SatiLite Wall-box Dimmer is not for use with electronic transformer low voltage incandescent lighting.

Dimensions

See image at the bottom of the page.

Catalog Numbers


# of Buttons	<u>Standard</u>
1	SAT-01-XX
2	SAT-02-XX



Example: SAT-01-W9 (1-button SatiLite with white faceplate and buttons.)

Note: Available faceplate options are as follows, W - White, V - Almond (Previously Ivory) and C - Black.

SatiLite Keypad Dimensions





SatiLite 3-Way Keypad

The SatiLite 3-way Keypad is for use with the SatiLite Wall-Box Dimmer when additional points of control are required. It is used to replace the toggle switch in a 3-way lighting installation and allow load control from a remote location.


White Steel with one white Button

Dimensions

See image at bottom left.

Catalog Number

S3W-X-XX



Note: Available faceplate options are as follows, W - White, V - Almond (Previously Ivory) and C - Black.



SatiLite to CCU Wiring Adapter

The SatiLite to CCU Wiring Adapter connects the SatiLite Wall-Box Dimmer to the CCU

via a CAT 5 connection. This adapter can be mounted in Low Voltage side of LT Enclosure, in a one-gang wall box, directly to Wall next to enclosures, or in a junction box per needed location in home.

Catalog Number 08-2020-04






Master Control Keypad

The Master Control Keypad (MCS) allows the user to control a maximum of 32 S, H or Eseries Control Keypads through a backlit LCD display. The keypads displayed on the MCScan be programmed, using the MCS Utility software and its RS-232 connection, to duplicate existing keypads throughout the home or can be unique to the MCS. The MCS is ideal for Master Bedrooms or where complete control of the entire home is desired. MCS is compatible with Standard, Compact and 5000LC CCUs. Because of its unique dimensions, the Master Control Keypads requires a specialty backbox (08-8026-02).

Catalog Number

MCS-XX



Strip The Strip recess m

Strip Switch Keypad

The Strip Switch is a four button Keypad that can be recess mounted into a typical door jamb. It allows the station to be hidden. It has no LED and does not require a backbox

Catalog Number

08-7101-02 (Specify one to four buttons)

PHONE: 801.486.8500




Slim-line Keypad

The Slim-line Keypad functions like a normal control Keypad with the advantage of a narrow footprint. It has a 1 1/2" wide faceplate, and can incorporate up to five horizontal buttons. It is available in all standard and custom finishes with H-Series buttons. Its narrow outline allows for place-

ment near door jambs, next to trim or it can even be inset into fixed furniture. (See page 16 for faceplate finish and button color options.)

Because of its unique dimensions, the Slim-line Keypad requires a specialty backbox

(08-8026-03). Catalog Number Base partrumber Button rumber Faceplate finish Button color



Manual Override Keypad

The Manual Override Keypad creates a direct connection to the manual override switches on the control modules. The Manual Override Keypad is visibly similar to a standard, S-Series, six button control Keypad. It

can be used as a tool for controlling the lights during the construction process, when keypads would not typically be installed. It can also be used as a back-up for groups of lights should the homeowner want to bypass the CCU. (See page 16 for faceplate finish and button color options.)


Catalog Number Available in six-buttons

only. All colors.

	MOS-XX	X
Base Part Number		
Faceplate —		
Bezel		
Button Color		



Data Input Keypad



Front View




Back View

The Data Input Keypad is a combination of a normal LiteTouch control Keypad and six data input terminals. It's perfect for connecting motion sensors, garage door openers, door jam sensors, security systems and other devices that require contact closure to send a message to the LiteTouch System. (See page 16 for faceplate finish and button color options.)

Indicate your choice of station style (S,H or E-Series).

Catalog Number




LTZ Keypad

The LTZ Keypad is an extension of the Data Input Keypad or Module. It can

be a cost savings solution for locations where a normal keypad may not be necessary. The LTZ Keypad is available in S or H Series Keypad configurations in White, Almond (previously Ivory) or Primecoat finishes. It comes in one to three button configurations and has no LED. (See page 16 for faceplate finish and button color options.)

Catalog Number Available in S and H-Series - White, Almond

(Previously Ivory) or Prime Coat only.





Corded Remote


The Corded Remote Keypad is a portable keypad that comes in any style and configuration. It has a ten foot cord that is plugged into the wall and can enhance boardrooms,

master bedrooms and media rooms. (See page 16 for faceplate finish and button color options.)

Catalog Numbers

Steel Box*	Oak Box
CRT-MXXX-XXXX	CRT-MXXO-XXXX
CRT-SXXX-XXXX	CRT-SXXO-XXXX
CRT-HXXX-XXXX	CRT-HXXO-XXXX
CRT-EXXX-XXXX	CRT-EXXO-XXXX
	CRT-MXXX-XXXX CRT-SXXX-XXXX CRT-HXXX-XXXX

* Indicate choice of Black, White or Almond (previously Ivory).



Audioaccess MRX Keypad




LiteTouch and Audioaccess have teamed up to provide a LiteTouch keypad as an option to control the Audioaccess MRX multi-room receiver. This allows both systems to be controlled from the same style keypad. Available in S and H-Series styles. (See page 16 for faceplate finish

and button color options.)

Catalog Number Base Partikumbe Station Style - S, or



Remote Infrared(IR) Receiver Keypad



This Keypad allows the user to control the LiteTouch system through a remotely placed IR sensor. The sensor is connected to a keypad by six inches of Receiver Wire. To place the sensor at a greater distance, Keypad Wire is provided to splice onto this wire. The Keypad can be mounted on the wall or in a concealed location.

Catalog Numbers (Single Gang)

S - Series 08-2800-02

H - Series 08-2800-03




Humid (Damp) Location Keypad

The Humid Location Keypad helps prevent water damage resulting from mild moisture conditions such as partially protected outdoor locations near a jacuzzi or pool. It consists of a one-gang Keypad and a humidity cover. Refer

to the S,H and E-Style Keypad information contained on page 16 in this catalog for Keypad ordering details. This information must be submitted at the time the order is placed.

Catalog Number





Waterproof (Wet) Keypad Backbox w/Keypad

The Waterproof Keypad Backbox is designed to protect the keypad from water damage (i.e. Keypads mounted in an outdoor environment in direct contact with the elements such as a boat dock or near beaches). The all-metal construction adds increased durability. The flange sinks flush with the wall leaving only a 4" door protruding from the wall. Available in white only.

This backbox must be installed before the drywall is hung.

Catalog Number

2580-010 (White backbox only.)

Infrared Remote Controls

The Universal Infrared Handheld Remote Infrared can control the LiteTouch System through multiple infrared-equipped H, S, E and one Metropolitan Series Keypads.

The backlit MX-700 remote can operate LiteTouch Metropolitan IR Series keypads and up to 20 other devices with customizable names that can be viewed on a large 2.3 inch LCD screen.

The MX-700 can store up to 74 commands for each of its 20 devices, plus a further 20 learned commands assigned to each device and 34 on the Main Menu--1534 learned functions.

Catalog Numbers

Universal Infrared Handheld Remote: 08-2300-01 (Must be factory programmed, please indicate station address at time of order.

MX-700 Remote: 08-2300-70





Keypad Options Ordering Key

The numbers and letters below are to be inserted in the Keypad catalog numbers to specify colors finishes and function.

Refer to the Keypad Catalog Number and

"Six Steps to Ordering a LiteTouch Keypad" to ensure your Keypad is ordered correctly.

Metropolitan Keypad **Options Ordering Key**

Standard Faceplate Finishes

MW - White

MV - Almond (Previously Ivory)

MC - Canvas

MB - Black

ME - Espresso

MF - Flax

ML - Melon

MS - Sky

MA - Prime Coat

Premium Faceplate Finishes

MN - Satin Nickel

MM - Satin Chrome

MP - Polished Chrome

MO - Dark Oil Rubbed Bronze

MH - Polished Gold

Button Colors

1 - Gray

2 - Black

4 - Brown

8 - Almond (Previously Ivory)

PHONE: 801.486.8500

9 - White

Text Engraving Fill Color

Please specify fill color on the Control Keypad Design Guide.

Note:

- Backlit selections are available with black buttons only.

Infrared

I - Infrared

X - No Infrared

- Additional lead time is required on all Premium Faceplate Finishes.
- Additional lead time and custom charges apply on custom keypads.
- For custom LED options please contact your Inside Sales Associate, additional charges may apply

S-Series, H-Series and E-Series **Keypad Options Ordering Key**

Standard Faceplate Finishes

W - White

V - Almond (Previously Ivory)

C - Black

A - Prime Coat

Premium Faceplate Finishes

D - Polished Stainless Steel

E - Satin Stainless Steel

H - 24K Polished Gold

I - 24K Satin Gold

J - Oil Rubbed Bronze

Button Colors

- 1 Gray
- 2 Black
- 4 Brown
- 8 Almond (Previously Ivory)
- 9 White

Infrared

I - Infrared

X - No Infrared

Note: Infrared option is <u>not</u> available in E-Series Control Keypads.


Text Engraving Fill Color

Please specify fill color on the Control Keypad Design Guide.

- Additional lead time is required on all Premium Faceplate Finishes.
- Additional lead time and custom charges apply on custom keypads.
- For custom LED options please contact your Inside Sales Associate, additional charges may apply



Standard Single-Gang Keypad Configurations






17

S and H-Series Double Gang Configurations

LiteTouch Standard double-gang stations are styled after the single-gang version but have more buttons for added load control. Choose

from these popular configurations in both S and H-Series. Call for catalog numbers.

S and H-Series Button Positions



Popular Custom Keypad Configurations

The sky's the limit as to the number of custom keypad options available. Choose from one of our standard keypads, or create something totally unique to you! At LiteTouch, the possibilities are endless. Call for catalog numbers. **Custom keypads require a longer lead time and must be price quoted by the factory.**

Euro Series

The Euro keypad is available in one to six Generation2 style buttons, and has an LED inset into the top center of each button. The faceplate of the Euro Keypad is a modified square. Choose between the standard green LED or an optional red one. Infrared capabilities are also available on this keypad in the fifth button position. Call for part numbers.

Euro Series Button Positions




Dimensions: 3 1/8" H x 3 1/8" H X 1 4/8" D

Horizontal H-Series

This series of Control Keypad is styled after the standard H-Series Keypad configuration. However, the buttons and the keypad have been rotated ninety degrees. Call for part numbers

Horizontal H-Series Button Positions



Dimensions:


2 13/16" H x 4 5/8" W x 1 4/8" D

PHONE: 801.486.8500 WEB: www.LiteTouch.com TECH SUPPORT 1.800.527.5527



S and H-Series Combination


These keypads combine up to three S-Series buttons on top of up to six H-Series buttons on a single-gang faceplate. Call for part numbers.




Dimensions: 4 5/8" W x 2 13/16" H x 1 4/8" D

Specialty

These two and three-gang Keypads combine H, E and S-Series configurations and even a traditional rocker-switch cut-outs to perfectly fit your application. Call for part numbers.



Two (1-6) and Three-Gang (7-12) Assorted Button Positions



Remember when placing orders for Custom Keypads please account for lead times and availability.

Dimensions:

4 5/8" H x 4 5/8" W x 1 4/8" D

SCENARIO





Scenario

Dimensions

External to wall: 4 7/16" H x 8" W x 7/32" D Internal to wall: 2 3/4" H x 7 1/4" W x 3 1/4" D (Mounts in a standard four-gang backbox)

Catalog Numbers

Scenario: 120 V: 08-8300-XX* ** 240 V: 08-8302-XX* **

*The first x represents faceplate finish. The second x represents button color. (See the **Keypad Options Ordering Key on page 16 for details.)**

**Extended lead times and pricing applies for premium faceplate finishes.

Note: Available faceplate options are as follows, W - White, V - Almond (Previously Ivory), C- Black and A - Prime Coat.

LiteTouch Scenario Keypad Wire

LiteTouch Scenario Wire is 20-gauge, five-conductor, non-shielded wire that provides data communication between Scenarios only. 08-2107-01*

*Specify length of wire in feet. Also specify Module or Station wire. Available in spools of 100, 250, 500 or 1000-feet only.

PHONE: 801.486.8500

The LiteTouch Scenario is a stand alone, wall-mounted, scene preset system capable of controlling up to four independent dimming or switching loads. Each load can be controlled in one of five ways. It can be turned on, turned off and dimmed with its own independent switch. It may be brought to a preset level (including off) by pressing a local scene switch. It may be brought to a preset level (including off) by pressing a scene switch on another Scenario. It may be turned off by using the local master. It may be turned off using the master off of another Scenario.

Each Scenario has four independent load control switches, four scene buttons, a master off button, and an IR receiver. Up to two Control keypads may be connected to each Scenario without the need for additional power supplies. These keypads can be configured with four, five or nine buttons (available in H-series only). The four button configuration offers control of the Scenario's four scenes. The fifth button acts as a switch between the four scenes and as a master off. The nine button station mirrors the Scenario.

Infrared remote capability is available on the five and nine-button remote keypads.

Note: The engraving schedule must be included with the order or the Scenario will be shipped with standard engraving (ex: Scene 1, Scene 2).

WEB: www.LiteTouch.com TECH SUPPORT 1.800.527.5527

ACCESSORIES & REPLACEMENT PARTS







RS232/Scenario Adapter

Allows communication to the Scenario via an RS-232 connection.

Catalog Numbers

Primecoat: 08-2250-01 White: 08-2250-02 lvory: 08-2250-03

Power Conditioning





Suppression Device

Line Conditioning and Suppression equipment provide a clean power environment against the LiteTouch Lighting Control System and protection for transient surges that may be harmful to electronic components.

Dimensions:

Omiphase: 4.25" W X 6.75" H X 4.5" D Suppression: 8" W X 11.5" H X 4.5" D

Catalog Numbers

Single Phase Omniphase: OSW120/240 EFI Three Phase Omniphase: OSW120/208 EFI Single Phase 3-Wire Suppression: MBP120EFI-Y2 Three Phase 4-Wire Suppression: MBP120EFI-Y3 Single Phase 3-Wire Suppression: MBP120EFI-Y2F Three Phase 4-Wire Suppression: MBP120EFI-Y3F

RS-232/RS-422 Converter & Cable

This is used to increase the distance of serial communication to the CCU. It is available in 51 to 150-foot units.

Catalog Number

08-2020-02



Line Filter Chokes

An Auxiliary Choke smoothest out the dimming cycle and quiets noisy lighting fixtures.

Catalog Numbers

10 Amp Auxiliary Choke: 08-3951-10 15 Amp Auxiliary Choke: 08-3951-15 20 Amp Auxiliary Choke: 08-3951-20



Transorb Board

LiteTouch Transorb Boards provide low voltage suppression ensuring protection from surges on the low voltage module communication line. One transorb board is found in each

enclosure for module connection.

Catalog Number





Wireless Modem

The Remote Modem was designed to provide end users with and easy communication link between the programmer's laptop and LiteTouch 5000LC CCU. This modem provides great functionality provided by the

serial connection, switch, indicator lights, high quality antenna, mounting plate and optional power source inputs. Each Modem includes a straight-through cable and a null adapter.

This unit has the best sensitivity in the industry, making it one of the longest range radio modems available to date, transferring data at 19200 baud up to 1/4 mile in a city environment or greater than 10 miles line-of-sight with a directional antenna.

Two units are required for communication. One to send and one to receive.

Catalog Number

Wireless Modem: 08-7004-01

ACCESSORIES & REPLACEMENT PARTS



System Event Recorder

The LiteTouch System Event Recorder tracks events of a LiteTouch system and records them into an ongoing date/time organized file.

The kit includes: 64 MB Flash Card, usb CF Card Reader, 120 VAC Power Supply, Power Cables and RS-232 Cable.

Catalog Number 08-2010-20

5000LC CCU Backplane Board



The 5000LC Backplane Board provides screw terminals for module and station wire runs to a 5000LC CCU. The backplane board has seven internal connectors to be used with the 5000LC card set.

Catalog Number 7002-116

Faceplate and Capture Plates



From time to time, customers may want to change the look of their stations. Order a different faceplate for a change of color or a different number of buttons.

Call factory for availability and catalog numbers.

Main Control Board

The Main Control Board is the brain behind each keypad. It is available for replacement in the field. Boards are only available for keypads with white pigtails in S, H and E styles only (please see the back of the main control board for pigtail color).

Catalog Number

7002-100

21

Surface Mount Switch Board

The Surface Mount Switch Board holds all of the functionality for the LiteTouch buttons. They are available for replacement in the field on S, H and E-Series keypads.

Catalog Numbers

S - Series: 7305-00X (specify button number)

H - Series: (1-5 buttons) 7305-025

(6-9 buttons) 7305-029

E - Series: 7104-01X (specify button number)

Module to Module Jumper Cable

The Module to Module Jumper Cable provides communication from one module to the next within the same enclosure. Each module ships with one cable. Replacement cables are available in 18" lengths.

Catalog Number

8000-003

Connector Cables

Connector Cables run from the CCU to a laptop during program uploading. Varying laptops require different cables - check your laptop for details.

Catalog Number

9 pin to 9 pin Connector Cable: 8002-909 9 pin to 25 pin Connector Cable: 8002-925

Control Module Wire

Control Module Wire connects LiteTouch Control Modules to the Central Control Unit.

Catalog Number

08-2105-01 (Specify length in feet: 100, 250, 500 and 1000)

Keypad Wire

Keypad Wire connects the LiteTouch keypads to the Central Control Unit.

Catalog Numbers

08-2103-01 (Specify length in feet: 100, 250, 500 and 1000)

PHONE: 801.486.8500 WEB: www.LiteTouch.com TECH SUPPORT 1.800.527.5527

ACCESSORIES & REPLACEMENT PARTS





Keypad 3-Pin Connector

Keypad 3-pin Connector (pigtails) connect each LiteTouch keypad into to the main line of keypad Wire.

All new LiteTouch keypads are shipped with white 3-Pin

Black 3-pin connector

Connectors. All keypads prior to October 1998 shipped with black 3-Pin connectors. (See the back of the main control board for 3-Pin Connector color.)



White 3-Pin Connector: 8002-003

Black 3-Pin Connector: 8002-001

Interface Cable For Computer Supply Rack

Available in 50-foot units.

Catalog Number

08-2020-01

Enclosure Neutral Bar

Enclosure Neutral Bars are mounted inside each Enclosure. They are available for replacement in the field.

Catalog Number

8090-001

Enclosure Ground Bar

Enclosure Ground Bars are mounted inside each Enclosure. They are available for replacement in the field.

Catalog Number

3399-001

Power Resister (Load Resister)

Keeps the dimming of a low-wattage load stable.

Catalog Number

8060-010

Replacement Fuses

Replacement fuse for Quad and 8 Channel Dimmer Modules as well as discontinued 8 Channel Relay Modules.

Catalog Numbers

8 Channel Relay Fuse (12 Amp Fuse): 3613-012

8 Channel Dimmer and Quad Fuse (15 Amp Fuse): 3613-020

Power Bus Monitor

Indicates, through a series of four LEDs located on the Module, that proper Module communication and proper wiring connectivity has been established, or is broken.

Catalog Number

7002-150

1/4 Amp Power Supply Fuse

Catalog Number 3617-000



3400 South West Temple, Salt Lake City, UT 84115 PH: 801.486.8500 FAX: 801.486.8569 Technical Support Line: 1-800-527-5527